

Concrete Block and Masonry:- Surfaces should be thoroughly clean and dry, with mortar and concrete aired for a minimum of 30 days @ 24oC. All loose mortar or other contaminants should be removed prior to application of any coating material. Surface temperatures must be at least 12oC before filling. Use appropriate filler for cracks or imperfections. Allow to dry thoroughly before top coating.

PREVIOUSLY PAINTED SURFACES

If in sound condition, clean the surface of all foreign material. Glossy surfaces must be rubbed down to provide a key. If paint is peeling or badly weathered, clean to sound substrate and treat as new.