

F151

STAINS & VARNISH

ALL-IN-ONE

CHARACTERISTICS

An interior/exterior finish that combines a high quality varnish with a stain to both beautify and protect wood from harmful UV radiation.

COLORS: Clear

COVERAGE:

First coat on bare wood: 12sq meters/lt
Second coat on wood: 18sq meters/lt
Third coat on wood: 22sq meters/lt

DRYING TIME:

200C, 50% RH
Touch: 3 hours
Hard Dry: 7 hours
Recoat: Overnight

FLASH POINT: 1020 F

FINISH: Gloss 96 units @ 600

SOLVENT/REDUCER: Mineral Spirits

Vehicle Type: Alkyd

WEIGHT SOLIDS: 50+/-2%

SPECIFIC GRAVITY: 0.92

PRECAUTIONS

Keep out of reach of children.

Ensure good ventilation during application and drying.

In case of contact with eyes rinse immediately with plenty of water.

To remove splashes from skin use soap and water or a recognised skin cleaner. Do not take internally.

Contains no added lead. APPLICATION

Stir gently before use.

BRUSH

No reduction necessary. Use a natural bristle brush. Avoid over-brushing which causes bubbling.

ROLLER

No reduction necessary. Use a 1/4" nap synthetic or lambswool roller cover. Remove any loose nap or lint by washing or wiping with a tack cloth prior to use. Avoid rapid rolling which causes bubbling.

PAD APPLICATOR

No reduction necessary.

SPRAY - AIRLESS

Pressure.....2000 psi
Tip......013"
Reduction.....none

SPRAY - CONVENTIONAL

Air Pressure.....50 psi
Fluid Pressure.....10 psi
Cap/Tip.....704/FF
Reduction.....up to 10%

CLEAN UP INFORMATION

Clean spills and splatters immediately with mineral spirits. Clean tools immediately after use with mineral spirits. Follow manufacturer's safety recommendations when using mineral spirits. SURFACE PREPARATION
Wood must be dry, free of dirt, grease, wax, polish, marks and old finishes in poor condition. Sand wood to a smooth surface and remove sanding dust with a vacuum or tack cloth.

FINISHING:**OVER BARE WOOD:**

1. Apply one coat of Stain & Varnish thinning 15-20% with White Spirits. Allow overnight drying.
2. Fill open grain wood or holes with proprietary natural wood filler.
3. Apply one or two more coats without thinning allowing overnight drying between coats and using fine carborundum paper to remove and mbs.

OVER PREVIOUSLY SEALED FINISHES IN GOOD CONDITION

4. Apply at full body to assure maximum film build and uniform sealing. Brush out evenly, avoid unnecessary brushing into already coated areas.
5. For heavy wear areas, allow the first coat to dry 18 hours, sand smooth, remove any sanding dust, and apply a second coat.