



Ready to Use Sugar Soap Spray

Bird Brand Sugar Soap is an easy, ready to use liquid that cleans and prepares all surfaces prior to repainting. Sugar Soap removes grease, grime and nicotine stains from painted surfaces. Also prepares newly stripped walls and generally improves paint adhesion. It is also an excellent general household cleaner.

Directions (shake bottle)

Spray directly and generously on to the surface. Wipe evenly all over the area using a sponge or absorbent cloth working from the bottom up to avoid run marks. Rinse after with fresh cold water and allow to dry completely. Tiles, vinyl floors and paint works will not require rinsing. For extra heavily soiled areas, the use of Bird Brand Powder or Concentrated Sugar Soap is recommended.

Precautions

To avoid the risk of spillage always ensure the trigger cap is secure in the closed position and the container remains upright during transportation and storage. Any spillage should be cleaned up immediately as spotting may occur.

Cover polished surfaces, lino, carpets and soft fabric furnishings to avoid splashing. Use only as directed, if in doubt test in a discreet area before use.

- Wear rubber gloves to protect skin.
- Irritating to eyes. Avoid contact with skin & eyes.
- In case of contact with eyes, rinse immediately with plenty of water and seek medical advice
- Not to be taken internally
- Keep out of reach of children.

This product contains amongst other ingredients: Less than 5% Anionic Surfactant
Less than 5% Non-Ionic Surfactant

WARNING

Sugar Soap is a traditional name for this product and refers to the crystalline structure. It is not made from sugar and should be kept away from children and animals.